

Battery Tray



1. Remove the battery. For additional information, refer to Battery and Battery Tray — Exploded View in this section.
2. Disconnect the wire harness retainers from the battery tray and position the wire harness aside.
3. Remove the 3 bolts from the battery tray and carefully position the battery tray aside to gain access to the washer reservoir electrical connector.
 - To install, tighten to 17 Nm (150 lb-in).
4. Disconnect the wire connector and washer hose from the washer bottle and remove the battery tray assembly.
5. To install, reverse the removal procedure.